





STEP 1: Plug in your Alexa device. If you have not set up your Alexa device, please follow Alexa's device setup instructions.


STEP 2: Download the Alexa app.




STEP 3: Sign up for (or sign into) your Alexa account.




STEP 4: Click the MORE icon (bottom right of mobile device).




STEP 5: Click "Skills & Games."




STEP 6: Search "Oelo Evolution" in the Search Bar.




STEP 7: Click the "ENABLE TO USE" button.



STEP 8: Link your Oelo account by using your Oelo Evolution login credentials.



STEP 9: Click "Next" to allow Alexa to discover your devices (Oelo Controllers/Zones) and scenes (Your Patterns).



STEP 10: Select an Oelo Controller or Oelo Zone and tap "Set Up Device."

Choose which connected device to set up first


You can delete connected devices anytime from the device settings page



STEP 11: Add your "device" to a "Group" to control multiple Oelo Zones together or to turn on/off other smart devices in tandem with your Oelo Lights. Example: Group other outside lights.

Where is your light?


Add your device to a group so you can control devices together, and say things like, "Alexa, turn on the Living Room."



STEP 12: Create Routines to enable Alexa to take multiple actions, like turning off your lights and other devices.

Choose which Routines you want to turn on

A Routine is when Alexa takes multiple actions at once for easier control. You can edit Routines or create your own anytime on the Routines page.



STEP 13: Command your lights! Use the commands on the back page!

USE YOUR INSIDE VOICE TO TURN ON YOUR OUTDOOR LIGHTS



TURN ON
OUTDOOR
LIGHTS

COMMAND	VARIABLE	ACTION	LIMITATION(S)
Alexa, turn on ... Alexa, run ... Alexa, set ...	[Oelo Zone or Alexa Group]	The specified lights turn on white, when color is not designated. (See next command to turn on colored light.)	TIP!: Give your Controller, Zones and Patterns simple names to help Alexa more easily understand commands.
Alexa, turn on ... Alexa, run ... Alexa, set ...	[Oelo Zone or Alexa Group] to [Color]	The specified lights will turn on, displaying the requested color.	Alexa only recognizes the following colors: red, orange, yellow, green, blue and white.
Alexa, turn on ... Alexa, run ... Alexa, set ...	[Oelo Zone or Alexa Group] at [Time]*	The specified lights turn on white at the requested time.	The time designation will only trigger your Oelo lights to turn on white.
Alexa, turn on ... Alexa, run ... Alexa, set ...	[Your Pattern] on [Oelo Zone]	The specified custom Pattern (from Your Patterns) will display on the commanded Oelo Zone.	Alexa will only recognize patterns that are saved under "Your Patterns." Alexa also cannot turn patterns on at a specified time.
Alexa, turn off ...	[Oelo Zone or Alexa Group]	The specified Zone or Group will turn off.	
Alexa ...	Goodnight.	The specified Zone or Group designated in your Routines turns off.	
Alexa ...	Let there be light.	The specified Zone or Group designated in your Routines turns on to white.	

* Note: If Oelo's scheduling feature is not functioning properly, please confirm you do not have any conflicting Alexa time commands.